



*vjgomez@isom.upm.es

XRD analysis of InGaN uniform layers grown on Si (111) without any buffer layers and on Sapphire


Víctor J. Gómez¹, Zarko Gacevic¹, Pavel Aseev¹, Paul E. D. Soto Rodriguez¹, Praveen Kumar¹, Enrique Calleja¹, Richard Nötzel¹ and Miguel A Sánchez¹
¹ ISOM, Universidad Politécnica de Madrid, Spain





Motivation

- III-nitrides combine:
- Direct and tunable band gap
 - High radiation resistance
 - High thermal conductivity
 - Large absorption coefficient
- Perfects for:
- Emitters
 - Solar cells
 - Lasers
 - Detectors

The direct growth on InGaN with various In composition on Si is highly desirable because high band gap buffer layers electrically isolate InGaN from the Si and therefore device design becomes complicated and costly.



PAMBE growth




- $\Phi_N = 3.7 \times 10^{14}$ atoms/(cm².s)
- $\Phi_{Ga} = 1.75 \times 10^{14}$ atoms/(cm².s)
- Φ_{In} varied between 0.3 and 1.1 $\times 10^{14}$ atoms/(cm².s)
- $T_g = 570^\circ\text{C}$

- $\Phi_N = 5.7 \times 10^{14}$ atoms/(cm².s)
- Φ_{Ga} varied between 3.9 and 5.2 $\times 10^{14}$ atoms/(cm².s)
- Φ_{In} varied between 1.3 and 2.9 $\times 10^{14}$ atoms/(cm².s)
- $T_g = 320^\circ\text{C}$


2

SEM images



SEM images of the samples grown on Si(111) at 320°C showing different In contents 10% for a), 25% for b) and 33% for c).


X-Ray Diffraction (XRD)





The correlation between tilt and In composition is shown and compared between growth on both substrates.

InGaN Pole Figures

The pole figures for samples with lower and higher In content are represented. The epitaxial orientation is determined as InGaN(0001)//Si(111) and InGaN[10-10]//Si[11-2].




X-Ray Diffraction (XRD)



Twist vs composition is shown.

The inset of the shows the ϕ scan of the sample with higher In content.


InGaN PL emission




Photoluminescence, up to room temperature, of the sample growth on Si(111) with higher In composition is shown.

3

Strain analysis



RSM sample grown on Si with higher In content



RSM sample grown on Template with higher In content

4

Conclusions

- InGaN layers grown directly on Si(111), without use of any buffer layer, with different In composition were characterized by means of HRXRD.
- Both tilt and twist show similar trend in Si and in GaN templates. Being higher for samples grown on Si.
- Pole figures show clearly the epitaxial relationship, demonstrating that the InGaN grows epitaxially on Si (111) with the epitaxial relation as InGaN(0001)//Si(111) and InGaN[10-10]//Si[11-2].
- Samples grown on Si were found to be relaxed in average. Samples grown on templates are highly strained.

Acknowledgements

The work was partly supported by the Spanish Ministry of Science and Innovation, project MAT2011-26703 and ETSIT UPM. P.K. acknowledges a Marie Curie Fellowship from the EC.

5